

Autonics

INDUCTIVE PROXIMITY SENSOR
CYLINDRICAL TYPE AC 2WIRE
INSTRUCTION MANUAL



Thank you for choosing our Autonics product.
Please read the following safety considerations before use.


Safety Considerations

- Please observe all safety considerations for safe and proper product operation to avoid hazards.
Warning Failure to follow these instructions may result in serious injury or death.
Caution Failure to follow these instructions may result in personal injury or product damage.
1. Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss.
2. Do not disassemble or modify the unit.
3. Do not connect, repair, or inspect the unit while connected to a power source.
4. Check 'Connections' before wiring.


Caution

- Use the unit within the rated specifications.
Use dry cloth to clean the unit, and do not use water or organic solvent.
Do not use the unit in the place where flammable/explosive/corrosive gas, humidity, direct sunlight, radiant heat, vibration, impact, or salinity may be present.
Do not supply power without load.


Ordering Information



Control Output Diagram & Load Operation



Connections



Specifications

Table with columns for Model, Sensing distance, Hysteresis, Standard sensing target, Setting distance, Power supply, Leakage current, Response frequency, Residual voltage, Affection by Temp., Control output, Insulation resistance, Dielectric strength, Vibration, Shock, Indicator, Environ-ment, Protection circuit, Protection, Cable type, Cable connector type, Insulation type, Material, Approval, and Unit weight.

*1: The response frequency is the average value. The standard sensing target is used and the width is set as 2 times of the standard sensing target, 1/2 of the sensing distance for the distance.
*2: Do not pull the 4mm cable with a tensile strength of 30N or over and the 5mm cable with a tensile strength of 50N or over.
*3: The weight with packaging and the weight in parentheses is only unit weight.

Dimensions





Table with columns for Item, Model, A, B, C, D, E, F, G, H, J (Unit: mm)


Connection of Power Supply

Be sure to connect the power after connecting the load, because direct connection of the proximity sensor may cause damage to the inner circuit of this product.



Mutual-interference & Influence by Surrounding Metals

Mutual-interference: When several proximity sensors are mounted closely, malfunction of sensor may be caused due to mutual interference. Therefore, be sure to keep a minimum distance between the two sensors, as below charts.



Influence by surrounding metals: When sensors are mounted on metallic panel, it is required to protect the sensors from malfunction by any metallic object. Therefore, be sure to keep a minimum distance as below chart.





Table with columns for Model, Item, A, B, l, Ød, m, n

Setting Distance




Sensing distance can be changed by the shape, size or material of the target. Therefore please check the sensing distance as (a), then pass the target within range of setting distance(Sa) as (b).

Setting distance(Sa) = Sensing distance(Sn)x70%
E.g.)PR30-10AO
Setting distance(Sa) = 10mmx0.7=7mm

Installation and Tightening Torque

When tightening the nut, use the provided washer as [Figure 1] according to the distance from the fore-end. The front part of the product is from the fore-end to the dimension on the below table, and the rear part is from the tip of the nut to the end of the product. In case the nut is placed in the front part of the product, apply tightening torque for front part. [Table 1] the allowable tightening torque table is for inserting the washer as [Figure 3].

Table 1: Tightening torque table with columns for Model, Strength, Front Size, Front Torque, Rear Torque.



Caution during Use

- Follow instructions in 'Cautions during Use'. Otherwise, it may cause unexpected accidents.
Wire as short as possible and keep away from high voltage lines or power lines, to prevent surge and inductive noise.
Do not use near the equipment which generates strong magnetic force or high frequency noise.
In case installing the product near the equipment which generates strong surge, use diode or varistor to remove surge.
Do not connect capacity load to the output terminal directly.
This unit may be used in the following environments:
1. Indoors (in the environment condition rated in 'Specifications')
2. Altitude max. 2,000m
3. Pollution degree 2
4. Installation category II

Major Products

- Photoelectric sensors, Fiber optic sensors, Door sensors, Door side sensors, Area sensors, Proximity sensors, Pressure sensors, Rotary encoders, Connector/sockets, Switching mode power supplies, Control switches/Lamps/Buttons, I/O Terminal Blocks & Cables, Stepper motors/drivers/motion controllers, Graphic/Logic panels, Field network devices, Laser marking system, Laser welding/soldering system, Temperature controllers, Temperature/Humidity transducers, SSR/Power controllers, Counters, Timers, Panel meters, Tachometer/Pulse/Rate meters, Display units, Sensor controllers.

Autonics Corporation logo and contact information including headquarter address in Busan, South Korea.

The above specifications are subject to change and some models may be discontinued without notice. Be sure to follow cautions written in the instruction manual and the technical descriptions (catalog, homepage).