


VDS6000 Series PC Oscilloscopes (VDS6102/A, VDS6152/A) User Manual



Copyright © Lilliput. All rights reserved. Licensed software products are owned by Lilliput or its subsidiaries or suppliers, and are protected by national copyright laws and international treaty provisions.

OWON products are covered by CHINA and foreign patents, issued and pending. Information in this user manual supersedes that in all previously published material. Specifications change privileges reserved.

OWON is the registered trademark of Lilliput.

Warranty

Thanks for choosing OWON product, in the coming days, really hope you will enjoy the time that OWON product accompanies you.

OWON product, created and made by Lilliput.

Since the delivery date, OWON product been granted 36 natural months' warranty for device, and 12 months' warranty for attached parts / accessories.

* The delivery date here means the one written onto formal shipping documents given to first-hand buying party.

Within warranty period of OWON product, provided any non-outside force defects appear, Lilliput provides 3 options for first-hand buying party -

- option 1. to return defective product only;
- option 2. to replace the defective product;
- option 3. to repair the defective product.

To assure the timely service within warranty period of OWON product, the first-hand buying party should notify Lilliput of the non-outside force defects in no time, in written form.

Lilliput recommends OWON product users to register your product online via "Support & Service" column from official English website , so as to get timely after-sales service.

This warranty shall not apply to any defect, damage caused by improper operation, or improper / inadequate maintenance towards OWON product. Lilliput shall not be obligated to under this warranty -

- a). repair damages resulted from attempts by personnel other than those from Lilliput, or authorized one by Lilliput to repair or service OWON product;
- b). repair damages resulted from improper operation, or improper connection to incompatible equipment towards OWON product;
- c). service OWON product that has been modified or integrated with other products, provided the effect of such modification or integration increases the difficulty of servicing non-original OWON product.

THIS WARRANTY IS GIVEN BY LILLIPUT WITH RESPECT TO OWON PRODUCT IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED. LILLIPUT AND ITS VENDORS DISCLAIM ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. LILLIPUT'S RESPONSIBILITY TO REPAIR OR REPLACE DEFECTIVE PRODUCTS IS THE SOLE AND EXCLUSIVE REMEDY PROVIDED TO THE CUSTOMER FOR BREACH OF THIS WARRANTY. LILLIPUT AND ITS VENDORS WILL NOT BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES IRRESPECTIVE OF WHETHER LILLIPUT OR THE VENDOR HAS ADVANCE NOTICE OF THE POSSIBILITY OF SUCH DAMAGES.

Table of Contents

I. General Safety Requirements.....	5
II. Safety Terms and Signs.....	6
III. PC Configuration Requirements.....	9
IV. Communication Interface Introduction.....	1 0
V. How to Communicate Device with PC.....	1 1
i. to install PC Software.....	1 1
ii. to install NI-VISA driver.....	1 1
iii. to run PC Software.....	1 4
iv. to communicate device with PC.....	1 5
VI. Operation Interface of PC Software.....	1 6
VII. Device Operation.....	1 9
i. how to set the probe compensation.....	1 9
ii. how to set the vertical system from PC software.....	1 9
iii. how to set the horizontal system from PC software.....	2 1
iv. how to set the trigger system from PC software.....	2 1
v. how to set channel from PC software.....	2 4
vi. how to use automatic measurement.....	2 6
vii. how to set sampling mode.....	2 8
viii. how to set built-in function generator.....	3 1
ix. how to use cursor measurement.....	3 1
x. how to set the display system.....	3 3
xi. how to change utility setting.....	3 5
xii. how to use main action button.....	3 6
xiii. how to use LAN communication interface.....	3 7
xiv. how to work WiFi with PC software.....	4 6
VIII. Technical Specifications.....	5 3
IX. Appendix.....	5 7
Appendix A. Device Accessory List.....	5 7
Appendix B. Device Maintenance.....	5 8

I. General Safety Requirements

! Before using the device, Lilliput strongly recommend to browse “**Safety Warnings**” carefully and completely, so as to avoid any possible body injury, or any damages to the device, or its accessories, or communicated facility. !

Safety Warnings

- i. The device only been allowed to work within specified application scenario.

- ii. Before communicating the device with PC, please refer to user manual to familiarize the allowed rating value completely.

- iii. Making sure the allowed rating value of all terminals been well-followed, so as to avoid any potential short circuit or electric shock.

- iv. NO direct body touch with any naked conductor of device when working the device. Naked conductor covers joints, connecting probe tip, communication interface, and others.

- v. No further operation is allowed provided any undetermined failure appears when working the device, better to seek the assistance of qualified technicians.

- vi. DO NOT work the device in humid environment.

- vii. DO NOT work the device in explosive environment.

- viii. Keep the device in good ventilation environment, and always keep the device surface clean and dry.

- ix. Better to have qualified technicians to do device maintenance.

II. Safety Terms and Signs

Safety Terms

Terms in this user manual. It covers,



Warning

It states the condition or the operation that may cause body injury or permanent life loss.



Caution

It states the condition or the operation that may cause device damage, or its accessory damage, or communicated facility damage.

Terms on the device. It covers,

Danger

It means the operation may result in the immediate body injury.

Warning

It means the operation may result in potential body injury.

Caution

It indicates the operation may result in potential damage to the device, or its accessory, or communicated facility.

Safety Signs

Signs on the device. It covers,



Hazardous Voltage



please refer to user manual for further details



Protective Earth Terminal



Chassis Ground



Communication Interface Ground

To avoid body injury, and to avoid device damage, its accessory or communicated facility damage, before working the device, Lilliput strongly recommend to read the following safety information.


 **Warning**

To avoid any potential short circuit or electric shock, DO use original local standard, or manufacturer's recommended power adapter.


 **Warning**

The channels of the device is non-isolated electrically. When working the device, to avoid short circuit, the ground of two probes are NOT allowed to connect to 2 different non-isolated DC level.

The illustration of the device's built-in ground wire connection -



When the device communicated with PC via USB communication interface (with PC powered by AC power source), the illustration of the ground wire connection -



It is NOT allowed to measure AC power when the device been powered by AC power source through the adapter, or when the device powered by PC through USB connection cable (via USB communication interface of PC, with PC powered by AC power source).



Warning

When the device input is getting through 42+ Vp-p (30Vrms), or on circuit of 4800+VA, to avoid any potential short circuit or electric shock -

- i. DO use only probes and adapter from original device accessories, or manufacturer's recommended ones.
- ii. Before working the device, DO check probes and accessories carefully to see whether any mechanical damages exists, making sure probes and accessories in normal status.
- iii. When device in non-working condition, to remove probes and accessories firstly, then put them in certain places.
- iv. When working the device in CAT II environment,
 - DO NOT get the 40+ V input voltage from earth surface through any non-isolated input;
 - DO NOT get the 40+ V input voltage of dropout voltage through any non-isolated input
- v. DO NOT introduce input voltage larger than rated voltage, especially when probe attenuation set in 1:1, since the voltage from probe tip will go through to the device itself.
- vi. NO NOT contact the exposed part of metal BNC terminal directly by hand or any other body part.
- vii. DO NOT insert any metal object into connectors.

- Note -

i). The rated voltage mentioned in point v. is the fixed value of working voltage, matching VACrms / 50 - 60Hz under AC sine wave application, and VDC under DC sine wave application;

ii). CAT II indicates local level for electrical appliance and portable device.

III. PC Configuration Requirements

Minimum System Requirement

CPU: Pentium® 4/ 2.4 GHz
Internal Memory: 1GB
Effective Hard Disk Space: 1GB

Recommended System Requirement

CPU: Pentium® Dual-Core/ 2.4 GHz
Internal Memory: 2GB
Effective Hard Disk Space: 2GB

Other Requirement

Operating System: Windows 10, or Windows 8 / 7 / Vista / XP (32-bit, or 64-bit)
Communication Interface: USB 2.0, or USB1.1; LAN
LCD Resolution: 1024 x 768, or above

IV. Communication Interface Introduction




Figure IV-1. Communication Interface of the Device

1. power input: for AC-DC adapter
2. USB host: for Wi-Fi extension
3. USB device (type-C): for PC communication

Note: when the device powered by PC through USB connection cable (via USB communication interface of PC, with PC powered by AC power source), without adapter connection, the input current should reach 1.5A or above

4. LAN: for PC communication within network
5. Built-in Signal (3.3 V/1 kHz) Output: for probe compensation
6. MULTI: for signal output of function generator
7. CH2: for signal input
8. CH1: for signal input

V. How to Communicate Device with PC

i. to install PC Software

- firstly, to get the software CD from accessories;
- secondly, to run .exe file from software CD on target PC;
- thirdly, to wait the PC software successfully installed onto target PC

Note: The PC software for OWON product also available from Lilliput official website


ii. to install NI-VISA driver

to run PC software normally, and smoothly, NI-VISA driver is a must.


Note: On condition that NI-VISA driver, or similar VISA driver already been well-installed onto the target PC, step ii could be skipped.

i). To download the installer via

ii). Based upon installer fully downloaded, to use mouse double-click it, to press "**OK**" to get access to the following window,




via "**Browse**" to choose the preferred folder, to click "**Unzip**" until full files unzipped.




Press "**OK**", to start NI-VISA driver installation.


iii). The following window comes,




via "Next", to enter into "Select the installation directories" window,




after locating installation path, click "Next",




then "Next", following window comes,



untick the box, then "Next",



dot-tick "I accept the above 2 License Agreement(s)", again "Next",



dot-tick "I accept the above 2 License Agreement(s)", to continue "Next".

Another "Next", based upon the step done, last "Next", eventually, press "Restart" until PC restarts, the full NI-VISA driver will be installed successfully.


iii. to run PC Software

Via short-cut to PC software from PC desktop, double-click "VDS6000 Series PC DSO" to start the software.


iv. to communicate device with PC


After powering the device via AC-DC adapter, its status indicator lights red for seconds.

Via USB connection cable (type-C), through matching communication interface, to connect the device with PC. When the status indicator lights green, PC software detects effective USB port, mouse-click the detected option to communicate the device with PC.







VI. Operation Interface of PC Software



1. Status Indicating Area: please refer to "Status Details List"
 2. Main Display Area
 3. Red Pointer: to indicate the horizontal position of one conditioned trigger
 4. Violet Pointer: to indicate the trigger position in the recorded data
 5. Time Range measured by certain cursor measurement
 6. Auto Set: please refer to [xii. how to use main action button](#)
 7. Run/Stop: please refer to [xii. how to use main action button](#)
 8. Single Trigger: please refer to [xii. how to use main action button](#)
 9. Back to Home of Function Menu
 10. Hide the current menu
 11. Voltage Range measured by certain cursor measurement
 12. Red Pointer: the trigger level position of Channel 1;
Yellow Pointer: the trigger level of Channel 2.
- Via dragging Red / Yellow Pointer upwards or downwards, to adjust the trigger level position of Channel 1 / 2.
13. Function Menu: to hide/show it via mouse-clicking  ; each side-bar icon matches corresponding function, please refer to Home of Function Menu for details -



14.  Shortcut to back to default factory settings, please refer to "[Default](#)" ;
-  Shortcut to export signal data, please refer to "[Pause & Export](#)"
-  Shortcut to switch between 3-window / 1-window VIEW. When working in 3-window VIEW, the upper-left window is for XY mode.
-  Shortcut to hide/show Function Menu
15. Trigger extension window, please refer to [iv. how to set the trigger system from PC software](#)
16. Sample and Period extension window, please refer to [iii. how to set the horizontal system from PC software](#)
17. Channel extension window for Channel 2, please refer to [ii. how to set the vertical system from PC software](#)
18. Channel extension window for Channel 1, please refer to [ii. how to set the vertical system from PC software](#)
19. Measurement Details extension window for Channel 1 and Channel 2, please refer to [vi. how to use automatic measurement](#)
20. Cursor Measurement extension window, please refer to [ix. how to use cursor measurement](#)
21. Yellow Pointer: to show the grounding base point (zero point) of Channel 2; provided no Yellow Pointer comes, it means Channel 2 is off.
22. Red Pointer: to show the grounding base point (zero point) of Channel 1; provided no Red Pointer comes, it means Channel 1 is off.
23. The Displayed Area of Input Signal of Channel 1.

Status Details List

i. following status appears when communicating the device and PC

Linking	the device is communicating with PC
Connect	the device successfully communicated with PC
Match	the PC software is matching the device as per model type
Syncing	the PC software is synchronizing the device's settings

ii. following status reflects the communication between the device and PC

Offline	no communication between PC software and the device
USBFound	the device found
USBDrvErr	USB driver installation error appears
MachineNotSupport	the device not identifiable

iii. following status indicates the working of the device

Auto	automatic trigger mode
Ready	ready for receiving trigger
Trig'd	signal triggered
Scan	slow scan mode
Stop	the device stops acquiring signal data
Error	error occurred
ReSyncing	re-synchronize with the device
AutoSet	in process of auto setting


Keyboard Shortcuts

F5	Run/Stop
Ctrl + Enter	Auto Set
Q	1 division less from Channel 1's voltage division
A	1 division more from Channel 1's voltage division
W	1 division less from Channel 2's voltage division
S	1 division more from Channel 2's voltage division
←	1 division less from time base
→	1 division more from time base


VII. Device Operation

i. how to set the probe compensation

Before working the probe with either of input channels (Channel 1 / Channel 2), better to adjust its compensation, so as to assure ideal measurement effect. Following operation steps to adjust probe compensation -

- i) From PC software operation interface, mouse-click  to get access to device function menu, choose "Channel";
- ii) then "CH1", set the "Probe Rate" at certain option (either **x1**, or **x10**, or **x100**, or **x1000**). Next, from physical probe, switch the probe attenuation to the matching option correspondingly.

Note: The probe compensation setting from function menu will keep valid until new setting change introduces.



Caution:
The default probe compensation setting into PC software reads **x10**, before working the probe with the device, making sure the probe compensation of both places is matching.





Figure VII- 1. Probe Attenuation Switch Position



Caution:
For physical probe, when the compensation set in **x1**, the probe itself will limit the device bandwidth at 5MHz.
To reach the full bandwidth, the physical probe's compensation should be set in **x10**, or above.


ii. how to set the vertical system from PC software

In "Channel extension window for Channel 1 / 2" (as item 18 and 17 described under [VII. Operation Interface of PC Software](#)), related options of vertical system could be adjusted accordingly.

The screenshot shows a software window with the following settings and annotations:


- Current channel**: 1 (indicated by a red arrow pointing to the channel number)
- Click to show/hide Channel menu**: (indicated by a red arrow pointing to the channel number)
- Click to switch coupling mode**: DC (indicated by a red arrow pointing to the coupling mode)
- Click to turn on/off current channel**: (indicated by a red arrow pointing to the close button 'x')
- Click to show voltage division combobox**: 500 mV/div (indicated by a red arrow pointing to the voltage division setting)
- Click to show zero point position slider bar**: 2divs (indicated by a red arrow pointing to the zero point position)
- frequency counter**: 1.024 kHz (indicated by a red arrow pointing to the frequency counter)

Through voltage divisions,




choose the ideal option.

Or through rotating the mouse wheel, to choose the ideal option.



Through zero point position control bar,



to reset zero point position will change the vertical position of the signal, via moving the slider upwards, or downwards - the farther slider from the center of control bar, the faster the vertical position changes.

Another solution is to drag the zero point pointer upwards or downwards (as item 22 and 21 goes under [VII. Operation Interface of PC Software](#)).

Keyboard Shortcuts


Q	1 division less from Channel 1's voltage division
A	1 division more from Channel 1's voltage division
W	1 division less from Channel 2's voltage division
S	1 division more from Channel 2's voltage division

Frequency Counter


The device gets built-in 6-digit frequency counter, with frequency measurement range starts from 2Hz till full bandwidth.

iii. how to set the horizontal system from PC software

Via “Sample and Period extension window” (as item 16 described under [VII. Operation Interface of PC Software](#)), related options of horizontal system could be adjusted accordingly.



Through horizontal position control bar,



to reset the horizontal position of the signal, via moving the slider leftwards, or rightwards - the farther slider from the center of control bar, the faster the horizontal position changes; or through dragging the red pointer to reset the horizontal position of the signal (as item 3 goes under [VII. Operation Interface of PC Software](#)).


Keyboard Shortcuts

- | | |
|---|--------------------------------|
| ← | 1 division less from time base |
| → | 1 division more from time base |

iv. how to set the trigger system from PC software

The “trigger” commands the device to capture the signal at what time, and then output the result - in the form of waveform. Once trigger been set properly, the output result will be valuable waveform over unstable signal segmentation.


How trigger works ? When trigger been set, before trigger condition met, the device will collect the data as more as possible so as to output the ideal result in the left side of the trigger point; then once trigger condition met, the device will capture the data continually, and completely to output the ideal result in the right side of the trigger point.

Mouse-click  to get access to Function Menu,

Note: For first operation, after mouse-clicking , the Home of Function Menu comes,



via  to choose "**Trigger**" option (or mouse-click  from right-bottom extension window to show this option).



The **Trigger** option here indicate single trigger, it is the one to use one trigger signal to capture data from two channels, simultaneously, the operation steps -


- i). choose "CH1" or "CH2" from "Source";
- ii). next "Mode", 4 options under "Mode": edge trigger, video trigger, slope trigger and pulse trigger.

Edge Trigger: when certain level gets through trigger signal input at certain direction, edge trigger happen

Video Trigger: field / line trigger on standard video signal
Slope Trigger: triggers on signal's rising / falling rate
Pulse Trigger: to capture certain pulse width at given trigger condition

1) Edge Trigger

- i). choose "Edge" from "Mode", to trigger on the threshold value of input signal;
- ii). choose "Rise" under "Edge" to trigger on the rising edge of input signal; and to choose "Fall" to trigger on falling edge of input signal;
- iii). click the voltage value after "Trigger" (below "Rise" or "Fall") to show slider bar. The Red / Yellow Pointer could be dragged to adjust the trigger level position, please refer to item 12 under [VII. Operation Interface of PC Software](#) ;



iv). use suitable "Trig Mode" from 3 options -

- Auto** in this trigger mode, the device could capture the signal without set trigger condition
- Normal** in this trigger mode, only capture the signal with set trigger condition met
- Single** in this trigger mode, only capture the signal once with set trigger condition met once, then stop

v). input "Hold Off" time

It's for setting the time interval to re-activate the trigger, the timespan ranges 100ns till 10s.

Setting method: choose "+" / "++" / "+++", click ▲, or ▼, the last/middle/first digit will go upwards/downwards by 1.

Click "Reset" after this option to get Hold-off time back to default status, say, 100ns.

Or to set options through "Trigger extension window":



Force (Trigger): to create a trigger signal by force, mainly work for "Normal" and "Single" mode under "Trig Mode".

2) Video Trigger

- i) choose "Video" from "Mode", to trigger on fields / lines of video signals;
- ii) choose NTSC, or PAL, or SECAM standard under "Video";

- iii) pick up one trigger synchronization method from Line / Field / Odd Field / Even Field / Line Number. The concrete line number could be set when "Line Number" is picked up.
- iv) Hold Off setting, please refer to point v) under **1) Edge Trigger**.

3) Slope Trigger











- i) choose "Slope" from "Mode", to set the trigger condition on the positive/negative slope within the specified time;
- ii) pick up suitable slope "Condition";
- iii) set slope time;
- iv) set the upper limit of "High Level", and the lower limit of "Low Level";
- v) set "Trig Mode", please refer to point iv) under **1) Edge Trigger** ;
- vi) set "Hold Off", please refer to point v) under **1) Edge Trigger**.

Slew rate comes as a result by auto-calculating, it = (High Level vale - Low Level value) / slope time




4) Pulse (Width) Trigger

- i) Choose "Pulse" from "Mode".
- Under pulse trigger, the pulse width decides the trigger time, and the unusual pulse could be captured through setting special pulse trigger condition.
- ii) pick up suitable pulse "Condition";
 - iii) set pulse time;
 - iv) set "Trigger" level;
 - v) set "Trig Mode", please refer to point iv) under **1) Edge Trigger** ;
 - vi) set "Hold Off", please refer to point v) under **1) Edge Trigger**.

Know more about icons from "Trigger extension window" -

-  Rise in Edge mode
-  Fall in Edge mode
-  synchronized trigger in Line under Video mode
-  synchronized trigger in Field under Video mode
-  synchronic trigger in Odd Field under video mode
-  synchronic trigger in Even Field under video mode
-  Rising Condition in Slope mode
-  Falling Condition in Slope mode
-  +Pulse Width Condition in Pulse mode
-  -Pulse Width Condition in Pulse mode

v. how to set channel from PC software

From Function menu, via  to choose certain channel, or to mouse-click  or  from "Channel extension window for Channel 1 / Channel 2" (please refer to item 18 / 19 under [VII. Operation Interface of PC Software](#)) to choose certain channel.



to turn on/ turn off Channel 1 / Channel 2

Press "CH1" or "CH2" to choose target channel, check "On" to turn on the target channel, uncheck "On" to turn off the target channel. As alternative method goes, from "Channel extension window for Channel 1 / Channel 2", click right-upper icon as marked below.



to invert a displayed waveform

waveform invert: to turn the displayed waveform in 180 degrees against the earth potential
 Press "CH1" or "CH2" to choose the target channel, check "Invert" to invert the displayed waveform in 180 degrees, uncheck "Invert" to back to normal display status.

to set bandwidth limit

Mouse-click "20M", or "Fullband"

20M: set the channel bandwidth at 20MHz - it's for reducing the noise of displayed waveform

Fullband: restore the channel bandwidth to full bandwidth.

to set channel coupling

DC: when this option chosen, both direct and alternating components of the input signal could get through

AC: when this option chosen, the direct component of the input signal will be shielded

Ground: when this option chosen, the input signal be disconnected

From "Channel extension window for Channel 1 / Channel 2", click certain icon functions the same.



to set the probe compensation

To assure ideal measurement result, the built-in probe compensation setting from Function menu should always match the one onto physical probe for target channel (please refer to [i. how to set the probe compensation](#)).

Giving one example: when the attenuation of the physical probe for target channel set in x1, the built-in probe compensation setting from Function menu should be set in x1 as well.

to measure current


It's possible to measure current via certain unit conversion, the detailed operation is, to use probe to measure the voltage drop across certain resistor.

Press "CH1" or "CH2" to choose target channel, then check "Measure Current On", via  or  to set the A/V ratio (Amps/Volts ratio).



Amps/Volts ratio = 1/Resistor value.

vi. how to use automatic measurement

From Function menu, via , enter into "**Measure**" option.

When moving the mouse at the main display area, on the left,  will appear, click it, the Measure menu will hide; another click will show the Measure menu.

Automatic measurement available in 20 options under Measure menu. From the left-bottom of the main display area, up to 8 measurement options could be accommodated.

All of 20 automatic measurement options go in Vpp, Vmax, Vmin, Vtop, Vbase, Vamp, Vavg, Vrms, Overshoot, Preshoot, Frequency (abbreviated as "Freq"), Period, Rise Time, Fall Time, Delay A→B , Delay A→B , +Width, -Width, +Duty, -Duty.


The "**Measure**" option covers several useful functions -

Show All: When choosing Channel 1, or Channel 2 from "Show All", one window will be called out, to show all of involved measurement values from Channel 1, or Channel 2.

Add measurement: Check CH1, or CH2, or both firstly, the measurement results will come in full details at the left-bottom of the main display area. Provided any/all of the current 8 measurement options not the required, another 8 measurement options possible to add for each channel. The new measurement option(s) will replace the current one(s) in the order of first till last.

Note: The measurement results of both channels possible to come together.


Remove measurement: Uncheck certain measurement option (20 options in total) to remove it. Mouse-click "Remove All" button to remove all of 20 measurement options.



automatic measurement options towards voltage value

10 options involved: Vpp, Vmax, Vmin, Vavg, Vamp, Vrms, Vtop, Vbase, Overshoot and Preshoot.

Following illustration to assist better understanding different measurement options,



Definitions about these options -


- Vpp** voltage between upper peak and lower peak from measured signal
- Vmax** voltage between upper peak and ground (GND)
- Vmin** voltage between lower peak and ground (GND)
- Vamp** voltage between flat top and flat base from measured signal
- Vtop** voltage between flat top and ground (GND)

- Vbase** voltage between flat base and ground (GND)
- Overshoot** equals $(V_{max} - V_{top}) / V_{amp}$
- Preshoot** equals $(V_{min} - V_{base}) / V_{amp}$
- Vavg** the arithmetic average voltage value of complete measured signal, or chosen part of measured signal
- Vrms** true RMS voltage value over complete measured signal, or chosen part of measured signal

automatic measurement options towards time measurement

10 options involved: Frequency (abbreviated as "Freq"), Period, Rise Time, Fall Time, +Width, -Width, Delay 1→2 \mathcal{F} , Delay 1→2 \mathcal{T} , +Duty and -Duty.


Following illustration to assist better understanding different measurement options,




Definitions about these options -

- Rise Time** the time span for signal amplitude rise from 10% to 90%, judged by the rising edge of its first pulse
- Fall Time** the time span for signal amplitude fall from 90% to 10%, judged by the falling edge of its first pulse
- +Width** the pulse width that the first positive pulse at 50% amplitude point
- Width** the pulse width that the first negative pulse at 50% amplitude point
- Delay 1→2 \mathcal{F}** the time delay of Channel 1 and Channel 2 at rising edge
- Delay 1→2 \mathcal{T}** the time delay of Channel 1 and Channel 2 at falling edge
- +Duty** measured by $+Width / Period$
- Duty** measured by $-Width / Period$

vii. how to set sampling mode

From Function menu, via , enter into "**Sampling**" option.




To know more about different sampling mode -

Sampling indicates normal sampling mode


Peak Detect this sampling mode always been used to capture interrupting signal noise

Average this sampling mode is to reduce random / irrelevant signal noise, with set range from 1 to 128 ($1 \leq \text{the set no.} \leq 128$)


Following illustration is signal output under normal Sampling mode, no interrupting signal noise been captured,



Following illustration is signal output under Peak Detect mode, the interrupting signal noise been captured in details,




Following illustration is signal output under Average mode, with average number set in 16, from here, the interrupting signal noise been reduced to certain degree,



vertical resolution option

this option is available only in VDS6102A / VDS6152A

Via "Precision Mode",





to know more about this option -

- 8 Bits** indicates the device works in 8-bit vertical resolution from ADC
- 12 Bits** indicates the device works in 12-bit vertical resolution from ADC
- 14 Bits** Indicates the device works in 14-bit vertical resolution from ADC

viii. how to set built-in function generator

The built-in function generator of 5MHz frequency output available from the device, with 4 basic waves output - sine, square, ramp and pulse, through MULTI communication interface.

From Function menu, via , enter into "Function Generator" option.



- i) choose preferred wave type from "Type", either Sine, or Square, or Ramp, or Pulse;
- ii) input Frequency range, remember to match its unit - Hz / kHz / MHz;
- iii) set Offset correctly

Further, Symmetry option comes under Ramp wave Type; and Duty Cycle option available in Pulse wave Type.

ix. how to use cursor measurement


From Function menu, via , enter into "Mark Cursor" option.



- i) check / uncheck measurement type, available in Time and Voltage option, cursor measurement works for either Time, or Voltage measurement, or both measurement at the same time;
- ii) when in Voltage measurement type, the target channel could be chosen from "CH1" and "CH2" option;


time cursor measurement: Check "Time" option, from the vertical direction of main display area, two lines in light color appears, indicating Cursor 1 and Cursor 2.

When moving mouse pointer through Cursor 1 or Cursor 2, it shapes \leftrightarrow , drag \leftrightarrow leftwards, or rightwards to adjust the measurement range between Cursor 1 and Cursor 2. The cursor measurement extension window (located at the bottom-left of main display area) tells the current time of Cursor 1 / Cursor 2, the absolute time difference between Cursor 1 and Cursor 2, and the frequency, as the illustration goes,



voltage cursor measurement: Check "Voltage" option, from the horizontal direction of main display area, two lines in light color appears, indicating Cursor 1 and Cursor 2.

When moving mouse pointer through Cursor 1 or Cursor 2, it shapes \updownarrow , drag \updownarrow upwards, or downwards to adjust the measurement range between Cursor 1 and Cursor 2. The cursor measurement extension window (located at the bottom-left of main display area) tells the current position of Cursor 1 / Cursor 2, the absolute value of the voltage amplitude difference between Cursor 1 and Cursor 2, as the illustration goes,



x. how to set the display system

From Function menu, via , enter into "Display" option.




Available in 2 display type, "Vector" and "Dots".


Vector to fill the room between the two adjacent sampling points, in dots of vector

Dots to display sampling points only

The signal displayed in Vector,



In contrast with the same signal displayed in Dots,



XY Mode

Check "XY Mode", the main display area switches to 3-window VIEW mode. In the XY mode window (upper-left window), the first channel reflects in X axis, the second channel in Y axis.

Note: When the device works in XY Mode, the record length been restricted at 1K points. The record length setting changes to 1K points automatically.

Persistence

When "Persistence" chosen, the device emulates the persistence display effect of CRO: the originally captured signal data in fading color, and the new data in fresh color, in cycle, continually.

The option of "Persistence" lasting available in Off, 0.5s, 1s, 2s, 5s, and Infinite, when set in "Infinite", the recording point continues to be there, until the persistence lasting option been changed. Press "Clear" to clear the current persistence.

Note: When any changes introduced towards time base, voltage division, or record length, or channel been turned on/off again, the current persistence will be cleared automatically, then to record the signal data after the aforementioned operation, again.

Grid Brightness

Drag the slider to adjust the grid brightness from main display area.

xi. how to change utility setting

From Function menu, via  , enter into "Utility" option,



Language

Available in 2 options: English and Chinese (simplified).

Skin

Works for operation interface skin color, either Black or Blue. After different color chosen from the current one, "Restart Effect" option comes, press "Restart" after the option, the PC software will restart in newly-set operation interface skin color.

Print Preview

Press the option to open the Print Preview Window for main display area.

The menus in Print Preview Window:

File

- Page Set** to set Printer Page Space
- Print** to print the current page onto chosen printer
- Exit** to close the Print Preview Window

View

- Page Transform** to switch the current page between horizontal and vertical layout
- Whole Page** function as full page display of the current page
- Face Size** to display the current page in its actual size
- Default Scale** to display the current page in preferred size (measured in %)

Show Wave Background Check the option to display the background color of main display area; uncheck the option to display the background color of previewed page.

Set Preview Page Background


Via this option, to change the background color of previewed page.

Save Image

To save the current page from main display area into .png, .bmp or .gif format image, excluding function menu page.

Pause & Export

Based upon the current record length, to export the captured signal in certain format file, with format supports .zip, .csv.

Mouse-click  from right-bottom functions the same as pressing "Pause & Export" button.

Self Cal


Via "Self Cal" operation, the device may reach the best ideal working status within short time, which assures the most accurate measurement result accordingly.

This operation works the device at anytime when the best ideal working status is a must. When the working temperature change hits $\pm 5^{\circ}\text{C}$, or exceeds $\pm 5^{\circ}\text{C}$, the device should do this operation.

Before doing this operation, remove off all device-connected-items, including but not limited to working probes / leads / clamps, then press "Self Cal", until the full process ends.

Default

Mouse-click "Default" to enter the device to default factory settings.

Mouse-click  from right-bottom functions the same.

Network

Through LAN, or WiFi, the device communicates with PC. Please refer to ["xiii. how to use LAN communication interface"](#) and ["xiv. how to work WiFi with PC software"](#).

Tips Window

4 categories' contents covered -

"Channel", "Capture&Period", "Trigger" and "Keyboard Shortcuts".

Under certain category, mouse-click any place from the current page to check the contents from next page.

Check "Don't show again" from right-top of this window, to disable this window, and it will not come when starting the PC software next time, until unchecking "Don't show again".

About

Via this option, to know the PC software version, device firmware version, device serial no., and official website information.

xii. how to use main action button

Main action button includes  (AutoSet),  (Run/Stop),  (Single Trigger), please refer to Item 6, 7, 8 under [VI. Operation Interface of PC Software](#) .

AutoSet

To set function items in certain value automatically, so as to generate more-suitable-for-observing waveform. Mouse-click **A** , the device capture the signal automatically, and promptly. The involved function items is as follows -

Trigger	
Trigger Type	Edge, or Video, as per the input signal
Trigger Mode	Auto
Trigger Coupling	DC
Trigger Slope	Rise
Trigger Level	mid-point setting
Channel	
Turn On / Off Channels	turn on the channel with signal input
Vertical Coupling	DC
Zero Point Position	been adjusted to the proper position
Vertical Scale	been adjusted to the proper division
Horizontal Level	middle
Horizontal Sale	been adjusted to the proper division
Sampling	
Run/Stop Status	Run
Acquisition Mode	current
Display	
Display Format	YT

Run/Stop

To start or stop sampling on input signals.

Single Trigger

To set trigger mode in “Single”, under this trigger mode, when set condition met, the device will capture the input signal once, then stop signal capturing.

Keyboard Shortcuts


Ctrl + Enter	AutoSet
F5	Run/Stop

xiii. how to use LAN communication interface

Through LAN communication interface, the device may communicate with PC directly, or via router connection

the device communicates with PC by direct LAN

- i) to check target PC's network setting
giving an example, here we set IP address in 192.168.1.71



- ii) to set device's network via "Network" button under "Utility" option
 - a. to communicate device with target PC through USB connection cable via suitable USB communication interface, after the communication successful (please refer to [iv. to communicate device with PC](#) under V. How to Communicate Device with PC), press "Network" button under "Utility" option from function menu
 - b. mouse-click "LAN Setup" to to enter into "MachineNetSetting" -
IP address: total in 4 sections, to set the first 3 sections the same as the one mentioned in part i), say, 192.168.1, the 4th section should be different, here do it in 192.168.1.252
Port: could try any value ranges from 0 till 65535, here put 8866
MAC: provided any reminder of "physical address conflict", change its value




c. press "OK" to finish the "MachineNetSetting"

iii) to add NI network device


a. device powering. Either through AC adapter, or through USB connection cable, the device been powered, with indicator lights red for seconds.

b. LAN connection. To communicate device with target PC through LAN connection, via respective LAN communication interface.

c. choose NI Max from Windows Start menu.




d. following page comes,




via “Devices and Interfaces”, then “Network Devices”, enter into “Add Network Device”

e. press  to,




dot-tick “Auto-detect of LAN Instrument”, then “Next”

f. to following window,



dot-tick “Select instrument(s) detected on local subnet”, to choose “TCPIP0::(the previous IP connection just added)::inst0::INSTR”, then mouse-click “Finish”.


g. back to PC software, to press TCPIP0::(the previous IP connection just added)::inst0::INSTR to communicate with PC software,



the device communicates with PC by router connection

i) to check target PC's network setting, the Netmask and Gateway setting should read the same as the one for router, giving an example, provided the router / PC's network setting goes in -

IP Address: 192.168.1.71
Netmask: 255.255.255.0
Gateway: 192.168.1.1



ii) to set device's network via "Network" button under "Utility" option

a. to communicate device with target PC through USB connection cable via suitable USB communication interface, after the communication successful (please refer to [iv. to communicate device with PC](#) under V. How to Communicate Device with PC), press "Network" button under "Utility" option from function menu

b. mouse-click "LAN Setup" to to enter into "MachineNetSetting" -

IP address: total in 4 sections, to set the first 3 sections the same as the one mentioned in part i), say, 192.168.1, the 4th section should be different, here do it in 192.168.1.252

Netmask: the same as the one for router

Gateway: the same as the one for router

Port: could try any value ranges from 0 till 65535, here put 8866

MAC: provided any reminder of "physical address conflict", change its value




c. press "OK" to finish the "MachineNetSetting"

iii) to add NI network device


a. device powering. Either through AC adapter, or through USB connection cable, the device been powered, with indicator lights red for seconds.

b. LAN connection. To communicate device with target PC through LAN connection, via respective LAN communication interface.

c. choose NI Max from Windows Start menu.




d. following page comes,




via “Devices and Interfaces”, then “Network Devices”, enter into “Add Network Device”

e. press  to,




dot-tick “Auto-detect of LAN Instrument”, then “Next”

f. to following window,



dot-tick “Select instrument(s) detected on local subnet”, to choose “TCPIP0::(the previous IP connection just added)::inst0::INSTR”, then mouse-click “Finish”.

g. back to PC software, to press TCPIP0::(the previous IP connection just added)::inst0::INSTR to communicate with PC software,



xiv. how to work WiFi with PC software

Note: Only the device equipped with optional WiFi module gets this function.

to work WiFi with PC software through device hotspot

The target PC should support WiFi communication, and the optional WiFi module should be inserted into USB host communication interface.

i) to set device's network via "Network" button under "Utility" option

a. to communicate device with target PC through USB connection cable via suitable USB communication interface, after the communication successful (please refer to [iv. to communicate device with PC](#) under V. How to Communicate Device with PC), press "Network" button under "Utility" option from function menu.

b. in "Network", mouse-click "WiFi Setup" to "WiFiSetting", choose "AP" as "Connect Type", to set "SSID" and "Password", "IP" here fill 192.168.100.1, "Port" here use 8866 (could be any value, ranging from 0 till 65536).



c. press "OK" to confirm the "WiFiSetting".

ii) to add NI network device

a. device powering. To disconnect the USB communication between the device and target PC, with AC adapter get through power source, then power the device, with indicator lights red for seconds.

b. WiFi communication. To communicate the device with target PC through WiFi hotspot set onto device, as per correct SSID and Password.

- Note -


Provided not possible to auto-switch between WiFi and LAN connection onto target PC, disable LAN.

Dot-tick "Obtain an IP address automatically" for the IP address onto target PC, or use the same first 3 sections of IP address set as point b. under i) part, say, 192.168.100

c. choose NI Max from Windows Start menu.




d. following page comes,




via "Devices and Interfaces", then "Network Devices", enter into "Add Network Device"

e. press  to,




dot-tick "Auto-detect of LAN Instrument", then "Next"

f. to following window,



dot-tick “Select instrument(s) detected on local subnet”, to choose “TCPIP0::(the previous IP connection just added)::inst0::INSTR”, then mouse-click “Finish”.

g. back to PC software, to press TCPIP0::(the previous IP connection just added)::inst0::INSTR to communicate with PC software,



to work WiFi with PC software through device station

The target PC should support WiFi communication, and the optional WiFi module should be inserted into USB host communication interface.

i) to set device's network via "Network" button under "Utility" option

a. to communicate device with target PC through USB connection cable via suitable USB communication interface, after the communication successful (please refer to [iv. to communicate device with PC](#) under V. How to Communicate Device with PC), press "Network" button under "Utility" option from function menu.

b. in "Network", mouse-click "WiFi Setup" to "WiFiSetting" choose "STA" as "Connect Type", to set "SSID" and "Password", "Port" here use 8866 (could be any value, ranging from 0 till 65536).



c. input correct "SSID" and "Password" from WiFi router, here we use one available WiFi router - SSID in OWONTM, Password in lilliputowon, press "OK" to confirm the setting, after the step, "WiFiSetting" menu will be off. Re-enter "WiFiSetting" menu, press "Refresh" to update the IP address.



ii) to add NI network device

a. device powering. To disconnect the USB communication between the device and target PC, with AC adapter get through power source, then power the device, with indicator lights red for seconds.


b. WiFi communication. To communicate the device with target PC through WiFi hotspot set onto device, as per correct SSID and Password.

- Note -


Provided not possible to auto-switch between WiFi and LAN connection onto target PC, disable LAN.

Dot-tick "Obtain an IP address automatically" for the IP address onto target PC, or use the same first 3 sections of IP address set as point b. under i) part, say, 192.168.100


c. choose NI Max from Windows Start menu.




d. following page comes,




via "Devices and Interfaces", then "Network Devices", enter into "Add Network Device"

e. press  to,




dot-tick “Auto-detect of LAN Instrument”, then “Next”

f. to following window,



dot-tick “Select instrument(s) detected on local subnet”, to choose “TCPIP0::(the previous IP connection just added)::inst0::INSTR”, then mouse-click “Finish”.

g. back to PC software, to press TCPIP0::(the previous IP connection just added)::inst0::INSTR to communicate with PC software,



VIII. Technical Specifications

- i. Set the probe compensation at x10 for physical probe;
- ii. Under suitable operation temperature, work the device for 30+ minutes without interval;
- iii. Provided the environment temperature gets 5 degrees more, or less, to self-calibrate the device through Utility menu, via "Self Cal" option (please refer to [Self Cal](#)).

The following technical specifications been measured on the basis of above operation,

Oscilloscope Part -

Bandwidth	VDS6102	100MHz				
	VDS6152	150MHz				
	VDS6102A	8-bit mode	100 MHz			
		12-bit mode	100 MHz			
		14-bit mode	20 MHz			
	VDS6152A	8-bit mode	150 MHz			
		12-bit mode	100 MHz			
14-bit mode		20 MHz				
Vertical Resolution (A/D)	VDS6102 VDS6152	8 bits				
	VDS6102A VDS6152A	8 bits / 12 bits / 14 bits				
Channel Q'nty	2					
Acquisition	Mode	sample, peak detect, average				
	Sampling Rate	VDS6102 VDS6152	2-CH working	500 MS/s		
			1-CH working	1 GS/s		
		VDS6102A VDS6152A	2-CH working	8-bit mode	500 MS/s	
				12-bit mode	250 MS/s	
				14-bit mode	100 MS/s	
		VDS6102A VDS6152A	1-CH working	8-bit mode	1 GS/s	
				12-bit mode	500 MS/s	
				14-bit mode	100 MS/s	
Input		Input Coupling	DC, AC, ground			
	Input Impedance	1 MΩ ± 2%, in parallel with 15 pF ± 5 pF				
	Supported Probe	x1, x10, x100, x1000				
	Max Input Voltage	40V (DC + AC Peak)				
	Bandwidth Limit	20MHz, or fullband				
	Channel Isolation	100 : 1 @ 50Hz; 40 : 1 @ 10MHz				
	Time Delay Between Channel (typical)	150 ps				

Horizontal System	Sampling Rate	VDS6102 VDS6152	2-CH working	0.5 Sa/s - 500 MSa/s		
			1-CH working	0.5 Sa/s - 1 GSa/s		
		VDS6102A VDS6152A	2-CH working	8-bit mode	0.5 Sa/s - 500 MSa/s	
				12-bit mode	0.5 Sa/s - 250 MSa/s	
				14-bit mode	0.5 Sa/s - 100 MSa/s	
			1-CH working	8-bit mode	0.5 Sa/s - 1 GSa/s	
	12-bit mode	0.5 Sa/s - 500 MSa/s				
	14-bit mode	0.5 Sa/s - 100 MSa/s				
	Interpolation	sin (x)/x				
	Max Record Length	10M				
Scanning Speed (s/div)	5 ns/div - 100 s/div, step by 1 - 2 - 5					
Sampling Rate / Relay Time Accuracy	±25ppm (typical, Ta = +25°C)					
Interval (ΔT) Accuracy (DC - 100MHz)	Single: $\pm(1 \text{ interval time} + 25\text{ppm} \times \text{reading} + 0.6\text{ns})$; Average>16: $\pm(1 \text{ interval time} + 25\text{ppm} \times \text{reading} + 0.4\text{ns})$					
Vertical System	Sensitivity	2 mV/div - 5 V/div				
	Displacement	± 2 V (2 mV/div - 50 mV/div) ± 20 V (100 mV/div - 500 mV/div) ± 40 V (1 V/div - 5 V/div)				
	Analog Bandwidth	VDS6102 VDS6102A	100 MHz			
		VDS6152 VDS6152A	150 MHz			
	1-CH Bandwidth	full bandwidth				
	Low Frequency	≥10 Hz (at input, AC coupling, -3dB)				
	Rise Time	VDS6102 VDS6102A	≤ 3.5 ns (at input, typical)			
		VDS6152 VDS6152A	≤ 2.3 ns (at input, typical)			
	DC Accuracy	VDS6102 VDS6152	±3% when ≥ 2mV			
		VDS6102A VDS6152A	±2% when ≥ 2mV			
DC Accuracy (average)	the voltage difference of any 2 points from the captured signal, after taking the average from ≥16 captured signals (ΔV): $\pm(2\% \text{ rdg} + 0.05 \text{ div})$					
waveform inverted ON / OFF						

Measurement	Cursor Measurement	ΔV and ΔT between Cursor 1 and Cursor 2	
	Automatic Measurement	Vpp, Vmax, Vmin, Vtop, Vbase, Vamp, Vavg, Vrms, Overshoot, Preshoot, Frequency, Period, Rise Time, Fall Time, Delay A→B $\frac{\mu}{s}$, Delay A→B $\frac{\mu}{s}$, +Width, -Width, +Duty, -Duty	
	Lissajous Figure	Bandwidth	full bandwidth
		Phase Difference	± 3 degrees
Communication Interface	USB device (type-C), USB host (Wi-Fi extension supported), LAN		
	Wi-Fi module available in option		
Frequency Counter	supported		

Trigger

Trigger Level Range	Internal	± 5 divisions from the screen center
Trigger Level Accuracy (typical)	Internal	± 0.3 division
Trigger Displacement	on the basis of record length and time base	
Trigger Hold-off Range	100ns - 10s	
Edge Trigger	Slope	rising, falling
Pulse Trigger	Trigger Condition	positive pulse: >, <, = negative pulse: >, <, =
	Pulse Width Range	30ns - 10s
Video Trigger	Modulation	supported standard: NTSC, PAL and SECAM broadcast systems
	Line Number Range	NTSC: 1 - 525; PAL / SECAM: 1 - 625
Slope Trigger	Trigger Condition	positive pulse: >, <, = negative pulse: >, <, =
	Time Setting	30ns - 10s

Function Generator Part -

Standard Waveform	sine, square, ramp and pulse
Frequency Output	5 MHz
Sampling Rate	25 MSa/s
Channel Q'nty	1
Vertical Resolution	10 bits
Output Impedance	50 Ω (typical)

Frequency

Sine	0.1 Hz - 5 MHz
Square	0.1 Hz - 200 kHz, with rising or falling time < 200ns
Ramp	1 Hz - 10 kHz, with rising or falling time $\geq 5\mu\text{s}$
Pulse	1 Hz - 10 kHz, with pulse width $\geq 5\mu\text{s}$

Amplitude

Output Amplitude	10mVpp - 5Vpp ($\leq 5\text{MHz}$) @ High Z
Amplitude Accuracy	$\pm(1\%$ of setting + 1 mVpp) (typical, 1kHz sine, 0V offset)
Amplitude Resolution	10 mVpp
DC Offset Range (AC+DC)	$\pm(2.5 V_{pk} - \text{amplitude } V_{pp}/2)$
DC Offset Accuracy	$\pm(1\%$ of setting + 1 mV + amplitude Vpp x 0.5%)
DC Offset Resolution	10 mVpp

General Part -

Communication Interface	USB Device, USB Host (hi-speed USB 2.0), LAN (10/100Mbps)
Programming Language	SCPI
Compatibility	USBTMC, LXI, SOCKET

Power

Power Source	5V - 15V DC / 1.2A
Power Consumption	$\leq 8\text{W}$

Environment

Temperature	working temperature: 0 °C - (+40 °C) storage temperature: (-20 °C) - (+60 °C)
Relative Humidity	$\leq 90\%$
Height	operating: 3,000 m non-operating: 15,000 m
Cooling Method	air convection (cross-ventilation)

Mechanical

Device Dimension	w/h/d 190 x 120 x 18 mm
Weight	0.38 kg

Device Calibration Time Interval

After the device been operated for every 12 natural months (calculated from the first operation day), better to calibrate it one time.

IX. Appendix

Appendix A. Device Accessory List

Accessories -

- 2 x passive probe
- 1 x USB connection cable (type-C)
- 1 x hard copy quick guide
- 1 x AC-DC adapter
- 1 x BNC/Q9 cable
- 1 x PC software / user manual CD

Optional Accessories -

- 1 x Wi-Fi module
- 1 x soft case

Note: Optional accessories is subject to extra purchasing.

Appendix B. Device Maintenance

Storage

To avoid any possible damage to the device, and probe, keep these items FAR AWAY from sprays, liquids, or solvents.

Surface Cleaning

As per the operation condition requirements, DO check the device and probe surface from time to time.

When cleaning the device / probe surface, please follow up with operation steps as follows -

- i. Before the surface cleaning, making sure the device been powered off, without any accessory / outer facility connected; making sure probe not working with device / outer facility.
- ii. Use non-electrostatic soft cloth to remove the surface dust.
- iii. For further surface cleaning, a wet-but-no-water-dripping soft cloth could be used, with soft detergent also works.

Note: To avoid permanent damage to the surface of device and probe, DO NOT introduce any corrosive chemical cleaner / detergent.



Warning:

After device surface cleaning, before working the device for next time, please confirm that the device surface in a relative dry condition, so as to avoid any short circuit risk, or possible body injury caused by electric conduction from the wet surface.
